


STORAGE BARN LEVELER Installation



1

Choose appropriate size
based on slope of land.

2

Place leveler on flat surface.
C channel slides over barn runners.

3

Use adjustable wrench to adjust.